# UNDERCOUNTER DISHWASHER

## MODELS:

MDB6769PAB3 (Black)
MDB6769PAW3 (White)
MDB6769PAS3 (Stainless)


© 2013 Maytag
Part No. W10612917 Rev. A

# DOOR AND PANEL PARTS



# DOOR AND PANEL PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | | Literature Parts |
| | W10435039 | Instructions, Installation |
| | W10490736 | Energy Guide |
| | W10596270 | Use & Care Guide |
| | W10580509 | Tech Sheet, English |
| | W10580510 | Tech Sheet, French |
| 2 | | Arm, Hinge |
| | W10274922 | Left Hand |
| | W10274921 | Right Hand |
| 3 | W10195120 | Stiffener, Door |
| 4 | | Panel Front |
| | W10420034 | Black |
| | W10420036 | White |
| | W10420038 | Stainless |
| 5 | | Access Panel |
| | W10369024 | Black |
| | W10369026 | White |
| 6 | W10073520 | Insulation, Door |
| 7 | | Fastener |
| | W10503548 | Black |
| | W10503549 | White |
| 8 | 304392 | Screw |
| 9 | 489470 | Screw |
| 10 | | Handle |
| | W10461636 | Black |
| | W10461635 | White |
| | W10324628 | Stainless |
| 11 | | Vent Grille, Assembly |
| | W10329548 | Black |
| | W10329549 | White |
| | W10398679 | Grey |
| 12 | W10316572 | Screw |
| 13 | W10195726 | Stud, Mounting |
| 14 | W10073540 | Insulation, Toe Panel |
| 15 | 8268961 | Sleeve, Friction |
| 16 | W10288004 | Nameplate |

# CONTROL PANEL AND LATCH PARTS



# CONTROL PANEL AND LATCH PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | | Console Assembly (Includes Active Overlay, Insert & Jumper Wire) (Includes Item 6) |
| | W10329522 | Black |
| | W10329521 | White |
| | W10329524 | Stainless |
| 2 | W10401190 | Box, Connector |
| 3 | W10539778 | Control, Electronic |
| 4 | W10194937 | Brace, Connector |
| 5 | W10550100 | Latch Assembly (Includes Switch) |
| 6 | W10401501 | Jumper, Wire |
| 7 | W10399027 | Screw |

# INNER DOOR PARTS



# INNER DOOR PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | W10348413 | Screw |
| 2 | W10462232 | Bracket, Dispenser |
| 3 | W10274924 | Inner Door Assembly (Also Order Item 6) |
| 4 | W10482094 | Cover, Dispenser |
| 5 | W10428211 | Vent Assembly (Also Order Item 6) |
| 6 | 8269259 | Gasket, Vent |
| 7 | W10274926 | Deflector, Vent (Also Order Item 6) |
| 8 | W10428217 | Dispenser, Assembly |
| 9 | W10329927 | Seal |
| 10 | W10496102 | Wiring Harness |
| 11 | W10177098 | Screw |
| 12 | W10274923 | Seal, Console/Door |
| 13 | W10524922 | Cap, Rinse Aid |

# FILL, DRAIN AND OVERFILL PARTS



# FILL, DRAIN AND OVERFILL PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | W10195037 | Lever, Overfill Switch |
| 2 | 8531412 | Hose |
| 3 | W10195536 | Inlet, Water (Also Order Item 4) |
| 4 | 8531323 | Gasket |
| 5 | W10508676 | Nut, Inlet (Also Order Item 4) |
| 6 | 371505 | Clamp, Hose |
| 7 | W10195047 | Fill Valve Assembly |
| 8 | 304392 | Screw |
| 9 | 371505 | Clamp, Hose |
| 10 | W10418848 | Drain Loop with Check Valve |
| 11 | W10195039 | Switch, Overfill Control |
| 12 | W10316267 | Standpipe, Overfill |
| 13 | W10346525 | Float & Retainer Assembly |
| 14 | W10292152 | Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets) |

# TUB AND FRAME PARTS



# TUB AND FRAME PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | W10266935 | Tub Assembly (Includes Heater Assembly) |
| 2 | W10195368 | Sound Insulation, Bottom |
| 3 | W10524469 | Seal, Tub |
| 4 | W10300779 | Strike, Latch |
| 5 | W10277003 | Screw |
| 6 | W10339474 | Thermostat |
| 7 | W10341745 | Screw |
| 8 | 3378595 | Clip, Thermostat |
| 9 | 8268990 | Bushing, Door Spring |
| 10 | W10271695 | Bottom Support |
| 11 | 8573239 | Shield, Tub Sound |
| 12 | 3378128 | Washer, Pronged Cup |
| 13 | 3400014 | Screw, Grounding |
| 14 | W10304228 | Leveler, Leg |
| 15 | W10165274 | Screw |
| 16 | W10337934 | Spring, Door Balance |
| 17 | W10505751 | Wheel & Mount Assembly |
| 18 | 3400892 | Screw |
| 19 | 8268991 | Cover, Terminal Box |
| 20 | W10339699 | Shield, Thermostat |
| 21 | 8269145 | Bracket, Undercounter |

# PUMP AND MOTOR PARTS



# PUMP AND MOTOR PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | 8534952 | Accumulator Assembly |
| 2 | 8283527 | Shield, Motor |
| 3 | W10348405 | Screw |
| 4 | 8572618 | Sump with Seal |
| 5 | 8268375 | Check Valve, Sump Assembly |
| 6 | W10083957 | Chopper Assembly |
| 7 | 9741232 | Screw |
| 8 | 8531857 | Protector Inlet |
| 9 | W10239404 | Motor Assembly |
| 10 | 3400217 | Screw |
| 11 | W10084567 | Screen, Separation |
| 12 | W10237169 | Sump & Motor Assembly |
| 13 | W10300599 | Tab, Sump |
| 14 | 8533949 | Nut |
| 15 | W10348269 | Pump, Drain |
| 16 | W10142656 | Volute, Back (Also Order Item 20) |
| 17 | 8269144 | Hose, Drain |
| 18 | W10239401 | Motor |
| 19 | W10134017 | Indicator, Optical Wash |
| 20 | 8531017 | Impeller Kit |
| 21 | W10334457 | Capacitor |
| 22 | 370445 | Clamp, Hose |

# UPPER WASH AND RINSE PARTS



# UPPER WASH AND RINSE PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | 8559850 | Feed Tube Assembly (Includes Item 3) |
| 2 | W10349488 | Screw |
| 3 | 8557720 | Sprayarm, Third Level |
| 4 | W10240137 | Manifold |
| 5 | W10199808 | Mount, Sprayarm |
| 6 | 8268433 | Seal, Sprayarm |
| 7 | W10082831 | Probe, Manifold |
| 8 | W10082841 | Sprayarm, Upper |
| 9 | W10118464 | Fastener, Push-In |
| 10 | W10199807 | Hanger |

# HEATER PARTS



# HEATER PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | W10134009 | Heater Element Assembly (Includes Item 2) |
| 2 | 717273 | Washer, Rubber |
| 3 | 8268548 | Nut, Heater Element |
| 4 | 8269262 | Bracket, Heater Support |
| 5 | W10343251 | Shield, Heater Probe<br>NOTE: If heater element is removed, it must be replaced. |

# UPPER RACK AND TRACK PARTS



# UPPER RACK AND TRACK PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | W10449113 | Dishrack, Upper |
| 2 | W10323189 | Stop, Track (Non-Removable) |
| 3 | W10451914 | Wheel Assembly |
| 4 | W10195623 | Track Assembly |
| 5 | W10289765 | Cupshelf |

# LOWER RACK PARTS



# LOWER RACK PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | W10201658 | Dishrack, Lower |
| 2 | W10082868 | Wheel & Transport Assembly |
| 3 | W10199701 | Silverware, Basket Assembly |
| 4 | W10199681 | Lid, Silverware Basket |

# LOWER WASHARM PARTS



# LOWER WASHARM PARTS

| Illus. No. | Part No. | Description |
|---|---|---|
| 1 | W10330588 | Wash Arm Assembly |
| 2 | 8268343 | Cap, Internal Rear Feed |
| 3 | 8268340 | Bearing, Lower Sprayarm |
| 4 | W10077898 | Hub, Lower Sprayarm |

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORIES

| Illus. No. | Part No. | Description |
|---|---|---|
| | | SIDE PANEL KITS |
| | 8171656 | White |
| | 8171657 | Black |
| | 8171658 | Biscuit/Bisque |
| | 8171659 | Stainless Steel |
| | | MOISTURE BARRIER KIT |
| | 4396277 | Barrier Kit |
| | | DRAIN HOSE |
| | 3385556 | 12 Ft. |

## PAINT, TOUCH-UP (1/2OZ.)

| Illus. No. | Part No. | Description |
|---|---|---|
| | 72017 | White |
| | 72032 | Black |
| | 4392899 | Biscuit/Bisque |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| Illus. No. | Part No. | Description |
|---|---|---|
| | 350930 | White |
| | 285006 | Black |
| | 4392901 | Biscuit/Bisque |

## PAINT, BULK (1 QT.)

| Illus. No. | Part No. | Description |
|---|---|---|
| | 799344 | White |
| | 4392900 | Biscuit/Bisque |

## POWER CORD KIT

| Illus. No. | Part No. | Description |
|---|---|---|
| | 4317824 | Power Cord Kit (Included Cord & Misc. Hardware) |

## ANTI-TIP KIT

| Illus. No. | Part No. | Description |
|---|---|---|
| | 8171477 | Floor Mount Kit |
| | 8212560 | Side Mount Kit |

## DISHRACK REPAIR

| Illus. No. | Part No. | Description |
|---|---|---|
| | | TINE TIP REPAIR KIT (Enough for Two Complete Racks) |
| | 4396838 | White |
| | 4396840 | Grey |
| | 4396854 | Silver Atlantis |
| | | VINYL TOUCH-UP (4oz) |
| | 676453 | White |
| | 676455 | Grey |
| | 4396853 | Silver Atlantis |